






00-SGP153 250W Muli-Way Intelligent Dimmer with SOHO CM Grid Adapter & Knob


















ENKIN

PDM250

Enkin 250W Multi-Way Intelligent Dimmer





Markings & Standard(s) CE, UKCA, BS EN 60669-2-1

Operating Voltage 220-240V AC

Main Frequency 50Hz

Minimum Load 2W LED (2W Incandescant/Halogen)

Maximum Load 250W LED (250W Incandescant/Halogen)

Switch Type Multi-way

Dimming Protocol Trailing edge phase control

Mounting Box Depth (Min) 35mm

Terminal Capacity 1 x 4mm² / 1 x 2.5mm² / 3 x 1.5mm² / 4 x 1mm²

Terminal Markings C (Live), L (Load)

Neutral Required No

Short Circuit Protection Yes

Overload/Overcurrent Protection Yes

Thermal Protection Yes - Thermal resettable fuse

Soft Start Yes

Power Failure Previous state recall

Memory Non volatile

Min/Max Level Setting Yes - Following a defined procedure

Driving Mode Trailing Edge (TE) only

Product Dimensions 60.5mm x 14mm x 25mm

Climate Range 0°C to 40°C, humidity 0% to 95% non-condensing

Recommended Location Indoor use only

Maximum Installation Altitude 2000m

IP Rating IP2XD

Trademarks Enkin is a trading name of Trade Ivy. Registered in England Number: 10809945. Copyright © 2021





PDM250


Operating Voltage 240V ac Nominal Operating Frequency 50 Hz Dimming Technique Trailing edge phase control Compliance BS EN 60669-2-1

Load Symbol	Compatible Loads	Max Load	Min Load
- ∕∕-	Dimmable LED lighting	250W	2W
<u>-Ö</u> -	240V Incandescent & Halogen lamps	250W	2W
	Low voltage lighting with electronic transformers	250W	2W


Multi-Gang Switch De-Rating Chart					
1 Gang	2 Gang	3 Gang	4 Gang	5 Gang	
250W	212.5W	175W	137.5W	100W	

WIRING EXAMPLES


WIRING DIAGRAM - SINGLE DIMMER SWITCH



WIRING DIAGRAM - MULTIPLE DIMMER SWITCHES



Enkin 250W Multi-Way Intelligent Dimmer



OPERATING INSTRUCTIONS

MULTI-WAY DIMMING - FUNCTIONALITY

Multiple dimmers in a connected set (connected in parallel), will all share the same settings and dimming position, including high and low settings. Because of this, it is important to only use the same luminaire type, per set of dimmers to avoid any mismatch between high and low settings.

It is only necessary to perform any hi/low or reset button sequences on one of the dimmers connected in a set, this must be performed only after all dimmers on the circuit have been connected together.

A reset sequence must be performed if dimmers are added or subtracted from the circuit, or luminaire type is changed, and then hi/low setup repeated.

ON OFF & DIMMING FUNCTION

Dimmer switch is activated by pressing the dimmer shaft only, dimming function by rotating the dimmer shaft only.

REAR PANEL PRESS BUTTON - DIMMER SETUP SEQUENCES Setting the Minimum Level (Anywhere below 50% of range)

- 1. Whilst on, slowly adjust dimmer to your desired minimum brightness.
- 2. Push the rear setup button 3 times within 2 seconds.
- The LEDs will step up and down in brightness once to confirm the setting has been saved.

Setting the Maximum Level (Anywhere above 50% of range)

- 1. Whilst on, slowly adjust dimmer to your desired maximum brightness.
- 2. Push the rear setup button 5 times within 3 seconds.
- The LEDs will step up and down in brightness once to confirm the setting has been saved.

Factory reset for Min/Max brightness

Please note this factory reset will reset all the min and max brightness settings.

- 1. Whilst on, push the rear setup button 7 times within 5 seconds.
- 2. The LEDs will step up and down in brightness three times to confirm that the min/max setting has been cleared.

